



# Rainbow Synthetic Clear Varnish

Rainbow Synthetic Clear Varnish is very Pale Color Product. This can be used on Wood, Cane Furniture and Tin Printing. It is also used to improve the gloss of Synthetic Enamels.

### Specification:

Composition

**Covering Capacity** 

Film Thickness

Number of Coats

**Drying Time** 

Oven

Application

Flash Pint

Gloss

**Packing** 

Synthetic Alkyd base

16-18 Sq. Mtrs / Litter / Coat

20-25 micron per coat

2 Coats

Surface 2-3 hours Recoatable 16 hours

120°C for 10 minutes (for Tin Printing)

Brush, Roller, Spray

73°F

**Full Glossy** 

750 Grams and 3 Kgs.

## Application Guide

### On Wood Surface

All new wood surface must be properly seasoned and dry. Apply two coats with an interval of 16 hours between the coats.

### Metal Surface

Rainbow Synthetic Varnish may be added up to 20% in all synthetic enamels to improve gloss.

Note: The above Information is given in good faith, but without any warranty.

Rainbow Paint Industries

Head Office:

CI-331, 16-B, Industrial Area, North Karachi, Karachi.

Ph: 021-36971166, 36971167, Cell: 0321-2111328 Email: karachi@rainbow-paints.com, Web: www.rainbow-paints.com

Quality & Standard Caint Manufacturer

Regional Office:

House No. 5 Lane No. 1, Scheme No. 02, PF Chowk Tipu Road, Chaklala Rawalpindi

Ph: 051-5590971, 051-5591436, 051-5961401